



Primary Exit Route



Fire Extinguisher Locations



Manual Call Point Locations



Mains Gas Inlet and Meter



Water Mains Shut Off Valve



The Assembly Point is Located in the Church Yard at the rear of the building